

AMF Panels



AMF panel is the short form of Auto Main Failure panel. It is normally connected to the generator set to control the generator set function. It can call the generator set if the AMF further connected to the Main Switch Board (received power from the other source - normally from the local authority) which equipped with auto transfer switch/automatic changeover contactor. While normal supply serve to main switch board failed, the AMF board will send the power failure signal to generator set. Then the generator set will run and serve the supply to main switch board.



Specifications

Available for upto 5000KVA.

Features

Consistent power supply to the load in absence of main supply.

DG set protections

Smooth Start / Stop Sequence

Protects the load from voltage fluctuations.

Mains failure and voltage fluctuations detection.

User friendly.

